


Instructions Firmware-Update testo 330 LL v2006

1. Installation of the Testo instrument driver

First, our instrument driver should be installed on your computer. This driver allow the computer and the instrument to communicate with each other.

Please, follow the next steps:

1. Open the file **USB Driver_2_8**
2. Run the file **TestoSetup** (double-click) and click “**next**” → The installation of the driver starts automatically




3. When the installation is completed, click “**close**” to finish the process.


2. Update of testo 330 LL v2006 (0632 3304 and 0632 3305)

Please, follow the next steps for the firmware update of testo 330 LL v2006:


1. Unplug the power supply and switch off the testo 330
2. Keep [▲] pressed
3. Connect the power supply, keep [▲] pressed → the instrument beeps and the red LEDs of the condensate trap blink. No information on the display.
4. Release [▲] .
5. Connect the instrument and the computer with the help of the connection cable 0449 0047
6. Open the file “**FW-Update testo 330 v2006**” and start the document „**USBFlashUpdate**” → „Testo USB Flash Update” starts
7. Click “**Browse**” on the following window:



8. Select the document “**t330A**” of the file “FW-Update testo 330 v2006” and click “**open**”:



9. Select the **testo 330** in the field „**USB Device**“ and select the value **921600** on the field „**Baudrate**“



10. Click „**Start**“ to start the update
11. When the update is succesfully complete, the following message appears:



12. Please confirm this message by clicking **OK** and „**close**“ the program „Testo USB Flash Update“.